



SIMPLIFIED INSTRUCTIONS FOR SETTING TIMED SOFTENER

PLUG IN TIMER TO TRANSFORMER LEAD AND REMEMBER TO SWITCH ON

BACKWASHING IS NECESSARY FOR THE OPERATION OF YOUR SOFTENER.

I. TO SET THE TIME WHEN BACKWASHING OCCURS

SET THE 24 HOUR (TME OF DAY) DIAL

A. TURN 'TIME OF DAY' DIAL WITH FINGERS UNTIL ROUND HOLE IN BLACK CIRCLE SHOWS THE TIME YOU WISH THE SYSTEM TO BACKWASH.

MOST PEOPLE CHOOSE 2am WHEN THERE IS LITTLE OR NO DEMAND FOR SOFT WATER. BACKWASHING TAKES ABOUT ONE HOUR.

B. TURN WHITE KNOB IN THE DIRECTION OF THE ARROW UNTIL THE PRESENT TIME SHOWS IN THE SQUARE HOLE ON THE METAL DIAL.

NB. REMEMBER THIS IS A 24 HOUR DIAL.

II. SET FREQUENCY OF BACKWASHING USING THE PIN DIAL

THIS DIAL DETERMINES HOW OFTEN BACK WASHING OCCURS. EACH PIN REPRESENTS A DAY.

A. TO BACKWASH EVERY DAY MAKE SURE ALL THE PINS ARE PUSHED DOWN.

B. TO BACKWASH EVERY OTHER DAY PULL UP EVER OTHER PIN.

C. TO BACKWASH EVERY TWO DAYS HAVE TWO PINS UP AND ONE DOWN AROUND THE DIAL.

III. SALT USAGE

SALT IS A WASHING AGENT AND IS USED FOR BACKWASHING ONLY. SALT DOES NOT AFFECT THE SOFTNESS OF THE WATER

A. ONLY USE SALT TABLETS.

B. KEEP THE CONTAINER THREE QUARTERS FULL OF SALT. AT FIRST CHECK LEVEL WEEKLY UNTIL YOU CAN JUDGE HOW OFTEN YOU NEED TO ADD SALT.